

QUANTA[®]



Process Signal Digital Panel Meter QXXXXP

Operator's Manual



NEWPORT Electronics, Inc.



<http://www.newportUS.com/manuals>

Additional products from
NEWPORT Electronics, Inc.

Counters	Rate Meters
Frequency Meters	Timers
PID Controllers	Totalizers
Clock/Timers	Strain Gauge Meters
Printers	Voltmeters
Process Meters	Multimeters
On/Off Controllers	Soldering Iron Testers
Recorders	pH pens
Relative Humidity	pH Controllers
Transmitters	pH Electrodes
Thermocouples	RTDs
Thermistors	Thermowells
Wire	Flow Sensors

For Immediate Assistance
In the U.S.A. and Canada: 1-800-NEWPORT®
In Mexico: (95) 800-NEWPORTSM
Or call your local NEWPORT Office.

NEWPORTnetSM On-Line Service
<http://www.newportUS.com>

Internet e-mail
info@newportUS.com

It is the policy of NEWPORT to comply with all worldwide safety and EMC/EMI regulations that apply. NEWPORT is constantly pursuing certification of its products to the European New Approach Directives. NEWPORT will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct but NEWPORT Electronics, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, patient connected applications.



This device is marked with the international caution symbol. It is important to read the Setup Guide before installing or commissioning this device as it contains important information relating to safety and EMC.

TABLE OF CONTENTS

SAFETY CONSIDERATIONS	ii
MAIN ASSEMBLY Q2000	
1.0 Specifications	1
2.0 Mechanical Assembly and Installation	4
3.0 Power & Signal Input Connections	5
4.0 Configuration Procedure	6
5.0 Configuration Charts	7
6.0 Tests and Diagnostics	8
7.0 Main Board Connector Pin Assignments	9
8.0 Drawings	10
MAIN ASSEMBLY Q9000	
9.0 Specifications	13
10.0 Mechanical Assembly and Installation	16
11.0 Power & Signal Input Connections	17
12.0 Configuration Procedure	18
13.0 Configuration Charts	19
14.0 Tests and Diagnostics	22
15.0 Main Board Connector Pin Assignments	23
16.0 Drawings	24
SIGNAL CONDITIONER BSCP	
17.0 Specifications	26
18.0 Signal Input Connections	28
19.0 Test and Diagnostics	29
20.0 Configuration Procedure	30
21.0 Configuration Charts	37
22.0 Calibration for Q2000P	46
23.0 Calibration for Q9000P	47
24.0 Drawings	48
INSTALLATION INSTRUCTIONS	
25.0 Digital Panel Meter Installation Instructions	49
26.0 Power Requirements and Connections	50

SAFETY CONSIDERATIONS



This device is marked with the international Caution symbol. It is important to read this manual before installing or commissioning this device as it contains important information relating to Safety and EMC (Electromagnetic Compatibility).

Unpacking & Inspection



Unpack the instrument and inspect for obvious shipping damage. Do not attempt to operate the unit if damage is found.

This instrument is a panel mount device protected in accordance with Class I of EN 61010 (115/230 AC power connections). Installation of this instrument should be done by Qualified personnel. In order to ensure safe operation, the following instructions should be followed.

This instrument has no power-on switch. An external switch or circuit-breaker shall be included in the building installation as a disconnecting device. It shall be marked to indicate this function, and it shall be in close proximity to the equipment within easy reach of the operator. The switch or circuit-breaker shall not interrupt the Protective Conductor (Earth wire), and it shall meet the relevant requirements of IEC 947-1 and IEC 947-3 (International Electrotechnical Commission). The switch shall not be incorporated in the mains supply cord.

Furthermore, to provide protection against excessive energy being drawn from the mains supply in case of a fault in the equipment, an overcurrent protection device shall be installed.



- The **Protective Conductor** must be connected for safety reasons. Check that the power cable has the proper Earth wire, and it is properly connected. It is not safe to operate this unit without the Protective Conductor Terminal connected.



- Do not exceed voltage rating on the label located on the top of the instrument housing.
- Always disconnect power before changing signal and power connections.
- Do not use this instrument on a work bench without its case for safety reasons.
- Do not operate this instrument in flammable or explosive atmospheres.
- Do not expose this instrument to rain or moisture.
- Unit mounting should allow for adequate ventilation to ensure instrument does not exceed operating temperature rating.
- Use electrical wires with adequate size to handle mechanical strain and power requirements. Install without exposing bare wire outside the connector to minimize electrical shock hazards.

EMC Considerations

- Whenever EMC is an issue, always use shielded cables.
- Never run signal and power wires in the same conduit.
- Use signal wire connections with twisted-pair cables.
- Install Ferrite Bead(s) on signal wires close to the instrument if EMC problems persist.

1.0 MAIN ASSEMBLY Q2000 SPECIFICATIONS

1.1 GENERAL

The Q2000 main assemblies are identified by an initial designator (BQ2) plus a power/display option numeral, zero thru nine (0-9).

The following table identifies the main assembly types:

Display Type	120 V ac	240 V ac	9-32 V dc	5 V ac	24 V ac
LED	BQ20	BQ22	BQ24	BQ26	BQ28
LCD	BQ21	BQ23	BQ25	BQ27	BQ29

The Digital Panel Meter/Controller consists of a main assembly, signal conditioner and interface options (if ordered) all housed in a 1/8 DIN case.

The main assembly consists of a main board and a display board which is permanently attached to it at a 90 degree angle.

The main board provides mounting for the power supply, circuit components, and connectors for plugging in the signal conditioner, optional analog card, and optional controller/communications interface card (requires removal of a bypass push-on jumper).

The display board includes the analog-to-digital converter, the LED or LCD display and the push-on jumper for programming the decimal points. Decimal point programming may also be done from the main board connector (J1).

1.2 POWER

AC Models:	24/120/240V +10/-15% 47-63 Hz
Common Mode Voltage:	1500 Vp test (354 Vp per IEC spacing)
DC Models:	5V \pm 5% (5V return common to signal LO) 9-32V (300V isolation from 9-32V return to signal LO)
Source Impedance:	3 Ohms
Ripple:	250 mV maximum
Power Consumption:	5 watts maximum

1.3 DISPLAY

LED:	14.2mm (0.56 in), 7-segment light emitting diode
Lens Color:	Red
LCD:	12.7 mm (0.50 in), 7-segment liquid crystal
Lens color:	Clear
Range:	0 to \pm 1999
Overload Indication:	Three least significant digits blanked, "1" or "-1" displayed

1.4 CONVERSION


Technique:	Auto-zero, dual slope, average value
Signal Integration Period:	100ms, nominal
Reading Rate:	2.5/s, nominal

1.5 ENVIRONMENTAL

Operating Temperature (Ambient):	0-60 °C
Storage Temperature:	-40 to 85 °C
Humidity:	To 95% RH, non-condensing, 0-40 °C

1.6 MECHANICAL

Case Material:	UL-rated 94V-0, polycarbonate
Weight:	0.57 kg (with interface board)




2.0 MECHANICAL ASSEMBLY & INSTALLATION

2.1 PANEL MOUNTING PROCEDURE (SEE FIGURE 1)

1. Remove the main board edge connector (J1), if installed.
2. Remove the interface board connector (J2), if installed.
3. Loosen two clamp screws on the rear of the case enough to rotate the two slide clamps.
4. Slide the two slide retainers toward the rear of the case and remove them.
5. From the front of the panel, insert the meter into the panel cutout.
6. Slide the slide retainers back onto the case and push up tightly against the rear of the panel.
7. Rotate the slide clamps back into their original position and tighten enough to hold the case in place. Overtightening can break the clamps.
8. Install any connectors removed.

2.2 LABELS (SEE FIGURE 2)




NOTE: READ LABELS FROM THE REAR

FIGURE 2. LABEL PLACEMENT

3.0 POWER & SIGNAL INPUT CONNECTIONS


WARNING: Incorrect power input can damage your PANEL METER.

3.1 POWER CONNECTIONS




Terminal Connection	AC Versions	Wire Color
1	AC power HI	Black
2	AC power LO (neutral)	White
3	AC power GND	Green

REAR TERMINAL VIEW




Terminal Connection	DC Versions
1	No connection
2	DC power +
3	DC power - (return)

3.2 SIGNAL INPUT CONNECTIONS



Terminal Connection	6 Terminal Versions Signal
4	Analog GND
5	Signal LO
6	Signal HI

REAR TERMINAL VIEW



Terminal Connection	7 Terminal Versions Signal
4	-E (Excitation return)
5	-S (Signal LO input)
6	+S (Signal HI input)
7	+E (Excitation output)


4.0 CONFIGURATION PROCEDURE

This procedure is used to set the decimal point of the display and interface board signal bypass selections for the configuration of the Q2000 Display and power options (BQ20 through BQ29).

The main assembly can be configured using the push-on jumpers provided or already positioned on the pin forests. Pin forest designations are shown at the top of every page of the configuration charts.


5.0 CONFIGURATION CHARTS

5.1 DECIMAL POINT SELECTION



Step 1: Remove all push-on jumpers not used in the desired configuration(s).		
Step 2: Select the desired configuration from the chart below, then install the push-on jumpers indicated.		
Decimal Point Selection	S1	Alternate Decimal Point Selection Using Main Assembly Board (J1) Connector
Decimal Point (1.999)	A	Connect J1-K/9 to J1-6
Decimal Point (19.99)	B	Connect J1-J/8 to J1-6
Decimal Point (199.9)	C	Connect J1-H/7 to J1-6
No Decimal Point (1999)	D	No Connection

5.2 INTERFACE BOARD SIGNAL BYPASS SELECTION



Step 1:	Check your Quanta part number for a zero (0) in the following position: Q2XX0X. If there is a zero (0) in that position, interface board signal bypass is required.	
Step 2:	Remove all push-on jumpers not used in the desired configuration(s).	
Step 3:	Select the desired configuration from the chart below, then install the push-on jumpers indicated.	
	Interface Board Signal Configuration	S2
	Interface Board Signal Bypass	A

6.0 TESTS & DIAGNOSTICS

6.1 TEST CONFIGURATION REQUIREMENTS

The main assembly is designed to function with a signal conditioner board as a minimum configuration. There is no provision for testing a main assembly alone.

6.2 SIGNAL INPUT REQUIREMENTS

Signal input requirements for your configuration are identified in the signal conditioner section of this manual.

7.0 Main Board Connector Pinouts (J1)


(Left to right, looking at rear of case)

Connection	Function	
A-1	Spare	
B	Oscillator	40 kHz
2	-8.2 V dc	Analog power
C-3	Spare	
D	+ Pol (sign)	+ Polarity sign
4	$\overline{\text{HOLD}}$	LED Version Only
E-5	Spare	
F	Buffer	Integrator output
6	Digital Ground	
H-7	199.9 (Decimal Point)	Use with pin 6
J-8	19.99 (Decimal Point)	Use with pin 6
K-9	1.999 (Decimal Point)	Use with pin 6
L-10	Test (LED version only)	Use with pin M/11
M-11	+5 V dc	Analog and Digital Power
N-12	Analog output	Standard 1 mV/count
P-13	Spare	
R-14	Spare	Used with H & S options -Excitation sense
S-15	Analog Ground	
T-16	Analog Option - Return	Used with analog option
U	Analog Option - Out	Used with analog Option
17	+30 V dc	Unregulated power
V-18	Spare	Used with S option +Excitation sense

-

Indicates common pin.


50 mA maximum power available from all internal sources.





REAR TERMINAL VIEW

8.0 DRAWINGS


8.1 DIMENSIONS




Notes: Dimensions are in inches ± 0.01 "
with millimeters in [] ± 0.25 mm.



Terminal block cover and bezel
not shown for clarity. Clamp
rings rotated and slide retainers
removed as shown for installation.



DWG. NO.
10256AY-04 B



DWG. NO.
10258AY-06 C

9.0 MAIN ASSEMBLY Q9000 SPECIFICATIONS

9.1 GENERAL

Q9000 main assemblies are identified by an initial designator (BQ9) plus a power/display option numeral: 0, 2, 4, 6 or 8.

The following table identifies the main assembly types:

Display Type	120 V ac	240 V ac	9-32 V dc	5 V ac	24 V ac
LED	BQ90	BQ92	BQ94	BQ96	BQ98


The QUANTA Digital Panel Meter/Controller consists of a main assembly, signal conditioner and interface options (if ordered) all housed in a 1/8 DIN case.

The main assembly consists of a main board and a display board which is permanently attached to it at a 90 degree angle.

The main board provides mounting for the power supply, circuit components, and connectors for plugging in the signal conditioner, optional analog card, and optional controller/communications interface card (requires removal of a bypass push-on jumper).

The display board includes the analog-to-digital converter, the LED display and the push-on jumper for programming the decimal points. Decimal point programming may also be done from the main board connector (J1).

9.2	POWER	
	AC Models:	24/120/240V +10/-15% 47-63 Hz
	Common Mode Voltage:	1500 Vp test (354 Vp per IEC spacing)
	DC Models:	5V \pm 5% (5V return common to signal LO) 9-32V (300V isolation from 9-32V return to signal LO)
	Source Impedance:	3 Ohms
	Ripple:	250mV maximum
	Power Consumption:	5 watts maximum
9.3	DISPLAY	
	LED:	14.2mm (0.56 in), 7-segment light emitting diode
	Lens Color:	Red
	Range:	0 to \pm 9999, digits flash from 10K-20K counts
	Overload Indication:	Four digits flash zeros at 20K and above
9.4	CONVERSION	
	Technique:	Auto-zero, dual slope, average value
	Signal Integration Period:	100ms, nominal
	Reading Rate:	2.5/s, nominal
9.5	ENVIRONMENTAL	
	Operating Temperature (Ambient):	0-60 °C
	Storage Temp.:	-40 to 85 °C
	Humidity:	To 95% RH, non-condensing, 0-40 °C
9.6	MECHANICAL	
	Case Material:	UL-rated 94V-0, polycarbonate
	Weight:	0.57 kg (with interface board)




10.0 MECHANICAL ASSEMBLY & INSTALLATION

10.1 PANEL MOUNTING PROCEDURE (SEE FIGURE 3)

1. Remove the main board edge connector (J1), if installed.
2. Remove the interface board connector (J2), if installed.
3. Loosen two clamp screws on the rear of the case enough to rotate the two slide clamps.
4. Slide the two slide retainers toward the rear of the case and remove them.
5. From the front of the panel, insert the meter into the panel cutout.
6. Slide the slide retainers back onto the case and push up tightly against the rear of the panel.
7. Rotate the slide clamps back into their original position and tighten enough to hold the case in place. Overtightening can break the clamps.
8. Install any connectors removed.

10.2 LABELS (SEE FIGURE 4)




NOTE: READ LABELS FROM THE REAR

FIGURE 4. LABEL PLACEMENT

11.0 POWER & SIGNAL INPUT CONNECTIONS


WARNING: Incorrect power input can damage your PANEL METER.

11.1 POWER CONNECTIONS




REAR TERMINAL VIEW

Terminal Connection	AC Versions	Wire Color
1	AC power HI	Black
2	AC power LO (neutral)	White
3	AC power GND	Green




Terminal Connection	DC Versions
1	No connection
2	DC power +
3	DC power - (return)

11.2 SIGNAL INPUT CONNECTIONS



REAR TERMINAL VIEW

Terminal Connection	6 Terminal Versions Signal
4	Analog GND
5	Signal LO
6	Signal HI



Terminal Connection	7 Terminal Versions Signal
4	-E (Excitation return)
5	-S (Signal LO input)
6	+S (Signal HI input)
7	+E (Excitation output)


12.0 CONFIGURATION PROCEDURE

This procedure is used to set the decimal point of the display and interface board signal bypass selections for the configuration of the Q9XXX display and power options (BQ90 through BQ98).

The main assembly can be configured using the push-on jumpers provided or already positioned on the pin forests. Pin forest designations are shown at the top of every page of the configuration charts.


13.0 CONFIGURATION CHARTS

13.1 DECIMAL POINT SELECTION




Step 1:	Remove all push-on jumpers not used in the desired configuration(s).	
Step 2:	Select the desired configuration from the chart below, then install the push-on jumpers indicated.	
Decimal Point Selection	S1	Alternate Decimal Point Selection Using Main Assembly Board (J1) Connector
Decimal Point (9.999)	A	Connect J1-K/9 to J1-6
Decimal Point (99.99)	B	Connect J1-J/8 to J1-6
Decimal Point (999.9)	C	Connect J1-H/7 to J1-6
No Decimal Point (9999)	D	No Connection

13.2 INTERFACE BOARD SIGNAL BYPASS SELECTION



Step 1: Check your Quanta part number for a zero (0) in the following position: Q9XX0X. If there is a zero (0) in that position, interface board signal bypass is required.	
Step 2: Remove all push-on jumpers not used in the desired configuration(s).	
Step 3: Select the desired configuration from the chart below, then install the push-on jumpers indicated.	
Interface Board Signal Configuration	S2
Interface Board Signal Bypass	A

13.3 REFERENCE VOLTAGE (RV1, RV2)



Step 1: Remove all push-on jumpers not used in the desired configuration(s).		
Step 2: Select the desired configuration from the chart below, then install the push-on jumpers indicated.		
Reference Voltage Configuration		S3
RV1	1 Volt	A
RV2	2 Volts	-

14.0 TESTS & DIAGNOSTICS

14.1 TEST CONFIGURATION REQUIREMENTS

The main assembly is designed to function with a signal conditioner board as a minimum configuration. There is no provision for testing a main assembly alone.


14.2 SIGNAL INPUT REQUIREMENTS

Signal input requirements for your configuration are identified in the signal conditioner section of this manual.

15.0 MAIN BOARD CONNECTOR PINOUTS (J1)

(Left to right, looking at rear of case)


Connection	Function	
A - 1	Spare	
B	Oscillator	100 kHz
2	-8.2 V dc	Analog power
C - 3	Spare	
D	+ Pol (sign)	+ Polarity sign
4	Hold	LED version only
E - 5	Spare	
F	Buffer	Integrator output
6	Digital Ground	
H - 7	XXX.X (Decimal Point)	Use with pin 6
J - 8	XX.XX (Decimal Point)	Use with pin 6
K - 9	X.XXX (Decimal Point)	Use with pin 6
L - 10	TEST	Use with pin M/11
M - 11	+5 V dc	Analog & digital power
N - 12	Analog output	Standard 1 mV/count
P 13	Spare	
R	Spare	
14	Used with H & S options - Excitation sense	
S - 15	Analog Ground	
T - 16	Analog Option - Return	Used with analog option
U	Analog Option - Out	Used with analog option
17	+30 V dc	Unregulated power
V - 18	Spare	Used with S option
-	+ Excitation sense	
-	Indicates common pin.	
	50 mA maximum power available from all internal sources.	





REAR TERMINAL VIEW

16.0 DRAWINGS

16.1 DIMENSIONS




Notes: Dimensions are in inches ± 0.01 "
with millimeters in [] ± 0.25 mm.



Terminal block cover and bezel not shown for clarity. Clamp rings rotated and slide retainers removed as shown for installation.

16.2 BQ9000 MAIN ASSEMBLY LED



U3	412	8	4	—
U2	247	16	—	8
U1	7135	11	—	24
DESIG	TYPE	+4.9V	-8.2V	GND

DWG. NO.
10410AY-04 B

17.0 SPECIFICATIONS: BSCP PROCESS SIGNAL CONDITIONER

17.1 GENERAL

This option board, identified as BSCP (Q2000-P or Q9000-P), provides extensive offset and scaling capability, permitting a wide selection of readout span for input current spans of 1 to 50 mA FS or for input voltage spans of 0.5 to 20 V FS. The Q2000 or Q9000 prefix is determined by the main assembly board used with the BSCP option board.

Selection of gain and offset ranges is made by push-on jumpers between 0.025" square pins on 0.1" centers. Six current ranges and six voltage ranges are provided, as well as push-on jumpers for offset and polarity to preserve the resolution and adjustability of the offset and gain potentiometers.

Formulas and computation procedures are supplied for calculating the proper model number based on the desired HI and LO input values and the top and bottom readout values chosen.

The BSCP has a restricted common-mode range: the BSCS strain gauge signal conditioner is recommended for signals with sizeable common-mode levels.

17.2 Q2000-P & Q9000-P: PROCESS SIGNAL INPUT SPECIFICATIONS

Configuration Single-ended, meter ground common to input LO.

Polarity Bipolar

Span Ranges Internally selectable by push-on jumpers
0 to 25%
25 to 50%
50 to 75%
75 to 100%

Zero Offset Ranges Internally selectable by push-on jumpers
-215 to -77 mV
-77 to +54 mV
+54 to +190 mV
+165 to +295 mV

Fine Zero Offset 50% of full scale minimum (front panel adjustment by potentiometer)

VOLTAGE RECEIVER

Readout Range	-1999 to +1999 (Q2000-P)						
Readout Range	-9999 to +9999 (Q9000-P)						
Input Range	0.5	1.0	2.0	5.0	10.0	20.0	V FS
Input Impedance	0.10	0.25	0.50	1.09	1.04	1.02	MOhms
Bias Current	100	50	25	13	13	13	pA
NMR at 50/60 Hz	60	56	54	50	50	50	dB

Maximum Voltage: 250 Vp

DC CURRENT RECEIVER

Readout Range	-1999 to +1999 (Q2000-P)						
Readout Range	-9999 to +9999 (Q9000-P)						
Input Range	1.0	2.0	5.0	10.0	20.0	50.0	mA FS
Maximum Current	16	22	35	50	70	112	mA
Shunt Resistance	499	249	100	49.9	24.9	10.0	ohms
Full Scale Voltage Drop	0.5	0.5	0.5	0.5	0.5	0.5	V FS
NMR at 50/60 Hz	60	60	60	60	60	60	dB

Common Mode

Analog ground to ac power ground

CMR at dc to 60 Hz	120 dB
CMV at dc to 60 Hz	± 1500 Vp per HV test ± 354 Vp per IEC spacing

Accuracy at 25 °C


Maximum Errors

Q2000-P	$\pm 0.05\%$ R ± 1 count
Q9000-P	$\pm 0.05\%$ R ± 2 counts
Reading Tempco	$\pm 0.01\%$ R/ °C
Zero Tempco	$\pm 0.01\%$ R/ °C
Warmup to rated accuracy	Less than 10 minutes

18.0 SIGNAL INPUT CONNECTIONS (TB1) (SEE FIGURE 5)

The signal input connections for the BSCP Process Signal Conditioner are made at the standard 3-terminal barrier strip:

<u>Terminal Connection</u>	<u>Signal</u>	<u>Input</u>
4	No Connection	•
5	-S Signal LO	• ——— -
6	+S Signal HI	• ——— +



REAR TERMINAL VIEW

FIGURE 5. SIGNAL INPUT CONNECTIONS

19.0 TESTS AND DIAGNOSTICS

- The signal conditioner board BSCP is designed to function with a main assembly as a minimum configuration. There is no provision for testing a signal conditioner board alone.
- Signal input requirements for your configuration are identified in the specifications for the BSCP signal conditioner.
- Operating power and connections for your configuration are identified in the Main Assembly Sections of this manual.

NOTE: If using Main Assembly Q2000, refer to Section BQ20/BQ29.

If using Main Assembly Q9000, refer to Section BQ90/BQ98.

- Inspect the panel meter for physical damage. If damage is apparent, contact the nearest Engineering Customer Service Department listed in this manual.

19.1 FUNCTIONAL ELECTRICAL TESTING

NOTE: Perform this test after your meter has been configured.

1. Short terminals 5 and 6 on barrier strip (TB1).
2. Apply proper power for your configuration to terminals 1, 2 and 3 on barrier strip (TB1). Display will read approximately the zero offset number (ZON) from Section 20.3.

20.0 CONFIGURATION PROCEDURE

20.1 GENERAL

Use this procedure to determine the configuration of the BSCP Process Signal Option.

Configure the unit using the push-on jumpers provided separately or already positioned on the pin forests. Pin forest designations are shown with each configuration chart.

20.2 GLOSSARY

The chart below explains various terms which appear throughout the following procedure:

<u>Voltmeter Range Selection</u>	<u>Input Range, Full Scale For Q2000-P & Q9000-P</u>
VM1	±190/235 mV
VM2	±233/350 mV
VM3	±348/450 mV
VM4	±440/580 mV
VM5	±575/850 mV
VM6	±800/1030 mV
VM7	±1.0/1.5 V
VM8	±1.4/1.8 V
VM9	±1.7/2.5 V
VM10	±2.4/3.1 V
VM11	±3.0/4.5 V
VM12	±4.4/5.1 V
VM13	±5.0/6.5 V
VM14	±6.4/9.6 V
VM15	±9.5/11.0 V

<u>Current Range Selection</u>	<u>Input Range, Full Scale For Q2000-P & Q9000-P</u>
AM1	±370/470 μ A
AM2	±460/700 μ A
AM3	±690/800 μ A
AM4	±790/940 μ A
AM5	±935/1400 μ A
AM6	±1.39/1.91 mA
AM7	±1.90/2.35 mA
AM8	±2.33/3.50 mA
AM9	±3.48/4.00 mA
AM10	±3.90/4.70 mA
AM11	±4.65/7.00 mA
AM12	±6.90/7.80 mA
AM13	±7.70/9.40 mA
AM14	±9.35/14.0 mA
AM15	±13.9/19.1 mA
AM16	±19.0/23.5 mA
AM17	±23.3/35.0 mA
AM18	±34.0/51.0 mA

Zero Offset Selection	Output Count Offset Range	
	Q2000-P	Q9000-P
ZO1	-3000/-1895	-15000/-9475
ZO2	-1900/-600	-9500/-3000
ZO3	-605/+870	-3025/+4350
ZO4	+865/+2100	+4325/+10500

Abbr	Definition
ZON	Zero Offset Number
LI	Lower Input Number
UI	Upper Input Number
LD	Lower Display Number
UD	Upper Display Number
G	Gain in Counts/Input

20.3 SELECTION

If the Input is to be configured as a:

- Voltmeter, proceed to Section 20.3.1
- Ammeter, proceed to Section 20.3.2
- Voltage Receiver, proceed to Section 20.3.3
- Current Receiver, proceed to Section 20.3.4

20.3.1 Voltmeter Range Selection VM1,2,3,4,5,6,7,8,9,10,11,12,13,14,15 *

1. Specify the magnitude of the largest + or - input voltage:
 Q2000-P: VM = _____Volts (For a 2000 count reading)
 Q9000-P: VM = _____Volts (For a 10000 count reading)
2. Select the lowest range where VM (from step 1) is equal to or less than the limit of that range.
 VM1 = 0.235 V VM6 = 1.030 V VM11 = 4.500 V
 VM2 = 0.350 V VM7 = 1.500 V VM12 = 5.100 V
 VM3 = 0.450 V VM8 = 1.800 V VM13 = 6.500 V
 VM4 = 0.580 V VM9 = 2.500 V VM14 = 9.600 V
 VM5 = 0.850 V VM10 = 3.100 V VM15 = 11.00 V
 VM = _____ This selection will be use in
 configuring the meter (Section 21.1).
3. Proceed to Installation (Section 20.4).

* Range Selection assumes that the meter has an offset range (ZO3) selected which allows a shorted input to read 000 on the Q2000-P display and 0000 on the Q9000-P display.

20.3.2 Ammeter Range Selection

(AM1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18) *

1. Specify the magnitude of the largest + or - input current.

Q2000-P = AM = _____ mA (For a 2000 count reading)

Q9000-P = AM = _____ mA (For a 10000 count reading)

2. Select the highest current range where AM is equal to or less than the limit of that range.

AM1 = 0.470 mA

AM7 = 2.350 mA

AM13 = 9.400 mA

AM2 = 0.700 mA

AM8 = 3.500 mA

AM14 = 14.00 mA

AM3 = 0.800 mA

AM9 = 4.000 mA

AM15 = 19.10 mA

AM4 = 0.940 mA

AM10 = 4.700 mA

AM16 = 23.50 mA

AM5 = 1.400 mA

AM11 = 7.000 mA

AM17 = 35.00 mA

AM6 = 1.910 mA

AM12 = 7.800 mA

AM18 = 51.00 mA

AM = _____ This selection will be used in configuring the meter (Section 21.2).

3. Proceed to Installation (Section 20.4).

20.3.3 Voltage Receiver Selection

VR1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18, 19, 20, 21, 22, 23, 24

1. Using the Input Span Range and the required display readings, calculate the zero offset required (with polarity).

(LI) Lower Input = _____

(UI) Upper Input = _____

(LD) Lower Display = _____

(UD) Upper Display = _____

2. When specifying the lower input (LI) and upper input (UI), the maximum display reading for a Q2000-P is ± 1999 . The maximum display for a Q9000-P is ± 9999 .

$$ZON = \frac{(LD \times UI) - (UD \times LI)}{(UI - LI)} = \underline{\hspace{2cm}}$$

3. Select a Zero Offset Range (ZO) from the appropriate Quanta series where the Zero Offset Number (ZON) falls between the minimum and maximum numbers of that range.

Q2000-P

Q9000-P

ZO1 = -3000/-1895

ZO1 = -15000/-9475

ZO2 = -1900/-600

ZO2 = -9500/-3000

ZO3 = -605/+870

ZO3 = -3025/+4350

ZO4 = +865/+2100

ZO4 = +4325/+10500

ZO = _____ This selection will be used in configuring the meter (Section 21.5).

4. Using the same LI, UI, LD, and UD numbers, calculate the Gain (G) in Counts/Input.

$$\text{Gain (G)} = \frac{(\text{UD} - \text{LD})}{(\text{UI} - \text{LI})} = \underline{\hspace{2cm}}$$

5. Select the group of four VR ranges under the Input Span Range required.
 6. Select one from this group which contains the Gain (G) number calculated in step 4.

Voltage Receiver Selection	Input Span	Output Count Range	
		Q2000P	Q9000P
VR1	0/0.5 V	80/2850	400/14250
VR2	0/0.5 V	2840/5500	14200/27500
VR3	0/0.5 V	5490/8170	27450/40850
VR4	0/0.5 V	8160/10600	40800/53000
VR5	0/1.0 V	40/1260	200/6300
VR6	0/1.0 V	1255/2440	6275/12200
VR7	0/1.0 V	2430/3605	12150/18025
VR8	0/1.0 V	3595/4700	17975/23500
VR9	0/2.0 V	20/750	100/3750
VR10	0/2.0 V	745/1452	3725/7260
VR11	0/2.0 V	1450/2157	7250/10785
VR12	0/2.0 V	2155/2750	10775/13750
VR13	0/5.0 V	8/231	40/1155
VR14	0/5.0 V	230/449	1150/2245
VR15	0/5.0 V	448/667	2240/3335
VR16	0/5.0 V	666/860	3330/4300
VR17	0/10.0 V	4/114.5	20/572
VR18	0/10.0 V	114/223	570/1115
VR19	0/10.0 V	222.5/331	1117/1655
VR20	0/10.0 V	330.5/428	1652/2140
VR21	0/20.0 V	2/56.8	10/284
VR22	0/20.0 V	56.5/110.3	282/551
VR23	0/20.0 V	110/164.4	550/822
VR24	0/20.0 V	164.2/220	821/1100

VR = _____ (Counts/Volts) This selection will be used in configuration (Section 21.3).

7. Proceed to Installation (Section 20.4).

20.3.4 Current Receiver Selection

CR1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19,20,21,22,23,24

1. Using the Input Span Range and the required Display Reading, calculate the zero offset required (with polarity).

(LI) Lower Input = _____

(UI) Upper Input = _____

(LD) Lower Display = _____

(UD) Upper Display = _____

2. When specifying the Lower Input (LI) and Upper Input (UI), the maximum display reading for a Q2000-P is ± 1999 . The maximum reading for a Q9000-P is ± 9999 .

$$ZON = \frac{(LD \times UI) - (UD \times LI)}{(UI - LI)}$$

3. Select a Zero Offset Range (ZO) from the appropriate Quanta series where the calculated Zero Offset Number (ZON) falls between the minimum and maximum numbers of that range.

Q2000-P

ZO1 = -3000/-1895

ZO2 = -1900/-600

ZO3 = -605/+870

ZO4 = +865/+2100

Q9000-P

ZO1 = -15000/-9475

ZO2 = -9500/-3000

ZO3 = -3025/+4350

ZO4 = +4325/+10500

ZO = _____ This selection will be used in configuring the meter (Section 21.5).

4. Using the same LI, UI, LD, and UD numbers used, calculate the Gain (G) in Counts/Input.

$$\text{Gain (G)} = \frac{(UD - LD)}{(UI - LI)} = \underline{\hspace{2cm}}$$

5. Using the chart on the following page, select the Count Output Range required for the Input Span Range chosen.
6. Select the group of four CR ranges under the Input Span Range required.
7. Select one of the four ranges which contains the Gain (G) number calculated.

Current Receiver Selection	Input Span	Count Output Range	
		Q2000P	Q9000P
CR1	0.2/1.0 mA	50/1405	250/7025
CR2	0.2/1.0 mA	1400/2730	7000/13650
CR3	0.2/1.0 mA	2725/4055	13625/20275
CR4	0.2/1.0 mA	4050/5264	20250/26320
CR5	0.4/2.0 mA	25/702	125/3510
CR6	0.4/2.0 mA	700/1365	3500/6825
CR7	0.4/2.0 mA	1363/2027	6815/10135
CR8	0.4/2.0 mA	2025/2632	10125/13160
CR9	1.0/5.0 mA	10/282.5	50/1413
CR10	1.0/5.0 mA	281.5/550	1408/2750
CR11	1.0/5.0 mA	548/816	2740/4080
CR12	1.0/5.0 mA	815/1059	4075/5295
CR13	2.0/10.0 mA	5/141	25/705
CR14	2.0/10.0 mA	140.5/274.5	702/1372
CR15	2.0/10.0 mA	274/407.5	1370/2037
CR16	2.0/10.0 mA	407/529	2036/2645
CR17	4.0/20.0 mA	2.5/70.4	13/352
CR18	4.0/20.0 mA	70.2/137	351/685
CR19	4.0/20.0 mA	136.6/203.4	683/1017
CR20	4.0/20.0 mA	203/264	1015/1320
CR21	10.0/50.0 mA	1/28.2	5/141
CR22	10.0/50.0 mA	28.1/55	141/275
CR23	10.0/50.0 mA	54.8/81.6	274/408
CR24	10.0/50.0 mA	81.5/106	408/530

CR=_____ (counts/mA) This selection will be used in configuration (section 21.4)

8. Proceed to Installation (Section 20.4)

20.4 INSTALLATION

20.4.1 General

If unit is to be configured as a voltmeter (VM1-15) or an ammeter (AM1-18) then zero offset (Z03) is required.

Select the Voltmeter (VM1-15), Ammeter (AM1-18), Voltage Receiver (VR1-24), Current Receiver (CR1,24), and/or the Zero Offset (Z01-4) required. Install the push-on jumpers as per Sections 21.1 through 21.5 depending on which range is required.

20.4.2 Reference Voltage (Q9000-P only)

Select reference RV2 by removing any jumpers on position S3 as per Subsection 13.3 in Main Assembly Section BQ90/BQ98.


20.4.3 Decimal Point

If a decimal point is required, refer to the appropriate Main Assembly Section for location and configuration procedure.

NOTE: If using Main Assembly Q2000, refer to Section BQ20/BQ29.
If using Main Assembly Q9000, refer to Section BQ90/BQ98.

21.0 CONFIGURATION CHARTS


21.1 VOLTMETER (VM1-6)



Step 1: Remove all push-on jumpers not used in the desired configuration(s).							
Step 2: Select the desired configuration from the chart below, then install the push-on jumpers indicated.							
Voltmeter Configuration*		S1	S2		S3		Input Resistance
VM1	±190/235 mV	B	C	D	G	-	100 kOhms
VM2	±233/350 mV	B	A	D	G	-	100 kOhms
VM3	±348/450 mV	B	B	C	G	-	100 kOhms
VM4	±440/580 mV	B	C	D	H	-	230 kOhms
VM5	±575/850 mV	B	A	D	H	-	230 kOhms
VM6	±800/1030 mV	B	C	D	J	-	385 kOhms

* Used on the Q2000-P or Q9000-P.


VOLTMETER (VM7-15)



Voltmeter Configuration*		S1	S2		S3		Input Resistance
VM7	$\pm 1.0/1.5$ V	B	A	D	J	-	385 kOhms
VM8	$\pm 1.4/1.8$ V	B	C	D	J	K	325 kOhms
VM9	$\pm 1.7/2.5$ V	B	A	D	J	K	325 kOhms
VM10	$\pm 2.4/3.1$ V	B	C	D	I	-	1 MOhm
VM11	$\pm 3.0/4.5$ V	B	A	D	I	-	1 MOhm
VM12	$\pm 4.4/5.1$ V	B	B	C	I	-	1 MOhm
VM13	$\pm 5.0/6.5$ V	B	C	D	K	-	1 MOhm
VM14	$\pm 6.4/9.6$ V	B	A	D	K	-	1 MOhm
VM15	$\pm 9.5/11.0$ V	B	B	C	K	-	1 MOhm

* Used on the Q2000-P or Q9000-P.


21.2 AMMETER (AM1-6)



Step 1: Remove all push-on jumpers not used in the desired configuration(s).							
Step 2: Select the desired configuration from the chart below, then install the push-on jumpers indicated.							
Ammeter Configuration*		S1	S2		S3		Input Resistance
AM1	±370/470 uA	B	C	D	A	G	490 ohms
AM2	±460/700 uA	B	A	D	A	G	490 ohms
AM3	±690/800 uA	B	B	C	A	G	490 ohms
AM4	±790/940 uA	B	C	D	B	G	240 ohms
AM5	±935/1400 uA	B	A	D	B	G	240 ohms
AM6	±1.39/1.91 mA	B	B	C	B	G	240 ohms

* Used on the Q2000-P or Q9000-P.


AMMETER (AM7-18)



Ammeter Configuration*		S1	S2		S3		Input Resistance
AM7	$\pm 1.90/2.35$ mA	B	C	D	D	G	100 ohms
AM8	$\pm 2.33/3.50$ mA	B	A	D	D	G	100 ohms
AM9	$\pm 3.48/4.00$ mA	B	B	C	D	G	100 ohms
AM10	$\pm 3.90/4.70$ mA	B	C	D	F	G	50 ohms
AM11	$\pm 4.65/7.00$ mA	B	A	D	F	G	50 ohms
AM12	$\pm 6.90/7.80$ mA	B	B	C	F	G	50 ohms
AM13	$\pm 7.70/9.40$ mA	B	C	D	E	G	25 ohms
AM14	$\pm 9.35/14.0$ mA	B	A	D	E	G	25 ohms
AM15	$\pm 13.9/19.1$ mA	B	B	C	E	G	25 ohms
AM16	$\pm 19.0/23.5$ mA	B	C	D	C	G	10 ohms
AM17	$\pm 23.3/35.0$ mA	B	A	D	C	G	10 ohms
AM18	$\pm 34.0/51.0$ mA	B	B	C	C	G	10 ohms


* Used on the Q2000-P or Q9000-P.

VOLTAGE RECEIVER (VR1-10)




Step 1:		Remove all push-on jumpers not used in the desired configuration(s).				
Step 2:		Select the desired configuration from the chart below then install the push-on jumpers indicated.				
Voltage Receiver Configuration		S2		S3	Counts/Volt Q2000-P	Counts/Volt Q9000-P
VR1	0.5 V Input	A	B	G	80/2850	400/14250
VR2	0.5 V Input	B	C	G	2840/5500	14200/27500
VR3	0.5 V Input	A	D	G	5490/8170	27450/40850
VR4	0.5 V Input	C	D	G	8160/10600	40800/53000
VR5	1.0 V Input	A	B	H	40/1260	200/6300
VR6	1.0 V Input	B	C	H	1255/2440	6275/12200
VR7	1.0 V Input	A	D	H	2430/3605	12150/18025
VR8	1.0 V Input	C	D	H	3595/4700	17975/23500
VR9	2.0 V Input	A	B	J	20/750	100/3750
VR10	2.0 V Input	B	C	J	745/1452	3725/7260

CURRENT RECEIVER (VR11-24)




Voltage Receiver Configuration		S2		S3	Counts/Volt Q2000-P	Counts/Volt Q9000-P
VR11	2.0 V Input	A	D	J	1450/2157	7250/10785
VR12	2.0 V Input	C	D	J	2155/2750	10775/13750
VR13	5.0 V Input	A	B	I	8/231	40/1155
VR14	5.0 V Input	B	C	I	230/449	1150/2245
VR15	5.0 V Input	A	D	I	448/667	2240/3335
VR16	5.0 V Input	C	D	I	666/860	3330/4300
VR17	10.0 V Input	A	B	K	4/114.5	20/572
VR18	10.0 V Input	B	C	K	114/223	57/1115
VR19	10.0 V Input	A	D	K	222.5/331	1110/1655
VR20	10.0 V Input	C	D	K	330.5/428	1652/2140
VR21	20.0 V Input	A	B	L	2/56.8	10/284
VR22	20.0 V Input	B	C	L	56.5/110.3	282/551
VR23	20.0 V Input	A	D	L	110/164.4	550/822
VR24	20.0 V Input	C	D	L	164.2/220	820/1100

VOLTAGE RECEIVER (CR1-10)




Step 1:		Remove all push-on jumpers not used in the desired configuration(s).					
Step 2:		Select the desired configuration from the chart below, then install the push-on jumpers indicated.					
Current Receiver Configuration		S2		S3		Counts/mA Q2000-P	Counts/mA Q9000-P
CR1	0.2/1.0 mA Input	A	B	A	G	50/1405	250/7025
CR2	0.2/1.0 mA Input	B	C	A	G	1400/2730	7000/13650
CR3	0.2/1.0 mA Input	A	D	A	G	2725/4055	13625/20275
CR4	0.2/1.0 mA Input	C	D	A	G	4050/5264	20250/26320
CR5	0.4/2.0 mA Input	A	B	B	G	25/702	125/3510
CR6	0.4/2.0 mA Input	B	C	B	G	700/1365	3500/6825
CR7	0.4/2.0 mA Input	A	D	B	G	1363/2027	6815/10135
CR8	0.4/2.0 mA Input	C	D	B	G	2025/2632	10125/13160
CR9	1.0/5.0 mA Input	A	B	D	G	10/282.5	50/1412
CR10	1.0/5.0 mA Input	B	C	D	G	281.5/550	1407/2750

CURRENT RECEIVER (CR11-24)



Voltage Receiver Configuration		S2		S3		Counts/mA Q2000-P	Counts/mA Q9000-P
CR11	1.0/5.0 mA Input	A	D	D	G	548/816	2740/4080
CR12	1.0/5.0 mA Input	C	D	D	G	815/1059	4075/5295
CR13	2.0/10.0 mA Input	A	B	F	G	5/141	25/705
CR14	2.0/10.0 mA Input	B	C	F	G	140.5/274.5	702/1372
CR15	2.0/10.0 mA Input	A	D	F	G	274/407.5	1370/2037
CR16	2.0/10.0 mA Input	C	D	F	G	407/529	2035/2645
CR17	4.0/20.0 mA Input	A	B	E	G	2.5/70.4	12/352
CR18	4.0/20.0 mA Input	B	C	E	G	70.2/137	351/685
CR19	4.0/20.0 mA Input	A	D	E	G	136.6/203.4	683/1017
CR20	4.0/20.0 mA Input	C	D	E	G	203/264	1015/1320
CR21	10.0/50.0 mA Input	A	B	C	G	1/28.2	5/141
CR22	10.0/50.0 mA Input	B	C	C	G	28.1/55	140/275
CR23	10.0/50.0 mA Input	A	D	C	G	54.8/81.6	274/408
CR24	10.0/50.0 mA Input	C	D	C	G	81.5/106	407/530

21.5 ZERO OFFSET (Z01-4)



Step 1: Remove all push-on jumpers not used in the desired configuration(s).			
Step 2: Select the desired configuration from the chart below, then install the push-on jumpers indicated.			
Zero Offset Configuration			
	Q2000-P	Q9000-P	S1
ZO1	-3000/-1895 counts	-15000/-9475 counts	A
ZO2	-1900/-600 counts	-9500/-3000 counts	C
ZO3	-605/+870 counts	-3025/+4350 counts	B
ZO4	+865/+2100 counts	+4325/+10500 counts	D

22.0 CALIBRATION FOR Q2000-P

NOTE: The numbers used below are derived from the selection Section 20.3.

22.1 VOLTMETER (VM1-15)

1. Apply a short to the input terminals and adjust the zero (Z) pot (R1) to make the display read 000.
2. Apply an Input Voltage equal to the largest (+) magnitude of the VM range selected and adjust the span (S) pot (R2) to make the display read the appropriate number.
3. Repeat above steps as required to set the display to within ± 1 count.

22.2 AMMETER (AM1-18)

1. Apply a short to the input terminals and adjust the zero (Z) pot (R1) to make the display read 000.
2. Apply an Input Current equal to the largest (+) magnitude of the AM range selected and adjust the span (S) pot (R2) to make the display read the appropriate number.
3. Repeat above steps as required to set the display to within ± 1 count.

22.3 VOLTAGE RECEIVER (VR1-24)

1. Apply a short to the input terminals and adjust the zero (Z) pot (R1) to make the display read the Zero Offset Number (ZON) calculated.
2. Apply an Input Voltage equal to the Upper Input (UI) number used and adjust the span (S) pot (R2) to make the display read that number.
3. Repeat above steps as required to set the display readings to within ± 1 count.

22.4 CURRENT RECEIVER (CR1-24)

1. Apply a short to the input terminals and adjust the zero (Z) pot (R1) to make the display read the Zero Offset Number (ZON) calculated.
2. Apply an Input Current equal to the Upper Input (UI) number used and adjust the span (S) pot (R2) to make the display read that number.
3. Repeat above steps as required to set the display readings to within ± 1 count.

23.0 CALIBRATION FOR Q9000-P

NOTE: The numbers used below are derived from the selection Section 20.3.

23.1 VOLTMETER (VM1-15)

1. Apply a short to the input terminals and adjust the zero (Z) pot (R1) to make the display read 0000.
2. Apply an Input Voltage equal to the largest (+) magnitude of the VM range selected and adjust the span (S) pot (R2) to make the display read the appropriate number.
3. Repeat above steps as required to set the display to within ± 1 count.

23.2 AMMETER (AM1-18)

1. Apply a short to the input terminals and adjust the zero (Z) pot (R1) to make the display read 0000.
2. Apply an Input Current equal to the largest (+) magnitude of the AM range selected and adjust the span (S) pot (R2) to make the display read the appropriate number.
3. Repeat above steps as required to set the display to within ± 1 count.

23.3 VOLTAGE RECEIVER (VR1-24)


1. Apply a short to the input terminals and adjust the zero (Z) pot (R1) to make the display read the Zero Offset Number (ZON) calculated.
2. Apply an Input Voltage equal to the Upper Input (UI) number used and adjust the span (S) pot (R2) to make the display read that number.
3. Repeat above steps as required to set the display readings to within ± 1 count.

23.4 CURRENT RECEIVER (CR1-24)

1. Apply a short to the input terminals and adjust the zero (Z) pot (R1) to make the display read the Zero Offset Number (ZON) calculated.
2. Apply an Input Current equal to the Upper Input (UI) number used and adjust the span (S) pot (R2) to make the display read that number.
3. Repeat above steps as required to set the display readings to within ± 1 count.

24.0 DRAWINGS

24.1 BSCP ASSEMBLY DIAGRAM




DWG. NO. 10288AY-01 F

25.0 DIGITAL PANEL METER INSTALLATION INSTRUCTIONS

IMPORTANT:

For proper installation electrical connections must be made according to the model number on the meter label. Write the model number in the following space and use the appropriate instructions for your model number.



Model number Q2 _____

Model number Q9 _____

25.1 UNPACKING & INSPECTION

Your digital panel meter was systematically inspected and tested, then carefully packed before shipment.


Unpack the instrument and inspect for obvious shipping damage. Notify the freight carrier immediately upon discovery of any shipping damage.

25.2 MECHANICAL INSTALLATION

1. Insure that the panel cutout dimensions are as shown on Figure 6.
2. Remove the lower printed circuit board edge connector, (if installed) J1, by pushing two molded plastic tabs away from the connector body and pulling the connector off the printed circuit board. Remove the printed circuit board edge connector, J2, if upper board output option was ordered.
3. Loosen two clamp screws on the rear of the case enough to rotate the two slide clamps.
4. Slide the two slide retainers toward the rear of the case and remove them.
5. From the front of the panel, insert the meter into the panel cutout.
6. Slide the slide retainers back onto the case and push up tightly against the rear of the panel.
7. Rotate the slide clamps back into their original position and tighten enough to hold the case in place. Overtightening can break the clamps.
8. Install the lower printed circuit board edge connector, if supplied, by pushing it on to the printed circuit board connections. Install the upper printed circuit board edge connector, if used.


PANEL THICKNESS

6,4 (.25) MAX
0,8 (.03) MIN




NOTE: Dimensions in Millimeters (Inches)

PANEL CUTOUT



REAR VIEW

(TERMINAL BLOCK COVER AND BEZEL NOT SHOWN FOR CLARITY)
SLIDE CLAMPS ROTATED AND SLIDE RETAINERS
REMOVED AS SHOWN FOR INSTALLATION.




26.0 POWER REQUIREMENTS AND CONNECTIONS (TB1)


The standard meter is wired to operate from one of five power sources

Models	Power Requirements
Q20XXX, Q21XXX, Q90XXX	120 V ac (50-60 Hz)
Q22XXX, Q23XXX, Q92XXX	240 V ac (50-60 Hz)
Q24XXX, Q25XXX, Q94XXX	9-32 V dc
Q26XXX, Q27XXX, Q96XXX	5 V dc
Q28XXX, Q29XXX, Q98XXX	24 v ac (50-60 Hz)

Regardless of the power source used, connections are made to the same terminal barrier strip, TB1, as follows:



REAR TERMINAL VIEW




TB1 Terminal Connection	AC Operation 24 V, 120 V, 240 V	Wire Color
1	AC power HI	Black
2	AC power LO (neutral)	White
3	AC power GND	Green

TB1 Terminal Connection	DC Operation 5 V or 9-32 V
1	No Connection
2	DC power +
3	DC power - (return)

26.0 SIGNAL INPUT CONNECTIONS (TB1)

The signal input connections for the BSCP Process Signal Conditioner are made at the standard 3-terminal barrier strip:

Terminal Connection	Signal	Input
4	No connection	•
5	- Signal LO	• ————— -
6	+ Signal HI	• ————— +



REAR TERMINAL VIEW

Warranty/Disclaimer

NEWPORT ELECTRONICS, INC. warrants this unit to be free of defects in materials and workmanship for a period of one (1) year from date of purchase. In addition to NEWPORT's standard warranty period, NEWPORT ELECTRONICS will extend the warranty period for one (1) additional year if the warranty card enclosed with each instrument is returned to NEWPORT.

If the unit should malfunction, it must be returned to the factory for evaluation. NEWPORT's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by NEWPORT, if the unit is found to be defective it will be repaired or replaced at no charge. NEWPORT's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of NEWPORT's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

NEWPORT is pleased to offer suggestions on the use of its various products. However, NEWPORT neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by NEWPORT, either verbal or written. NEWPORT warrants only that the parts manufactured by it will be as specified and free of defects. NEWPORT MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive and the total liability of NEWPORT with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall NEWPORT be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by NEWPORT is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, NEWPORT assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and additionally, purchaser will indemnify NEWPORT and hold NEWPORT harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

Return Requests/Inquiries

Direct all warranty and repair requests/inquiries to the NEWPORT Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO NEWPORT, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM NEWPORT'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting NEWPORT:

1. P.O. number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult NEWPORT for current repair charges. Have the following information available BEFORE contacting NEWPORT:

1. P.O. number to cover the COST of the repair,
2. Model and serial number of product, and
3. Repair instructions and/or specific problems relative to the product.

NEWPORT's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

NEWPORT is a registered trademark of NEWPORT ELECTRONICS, INC.

© Copyright 2007 NEWPORT ELECTRONICS, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without prior written consent of NEWPORT ELECTRONICS, INC.

For immediate technical or application assistance please call:

1-800-6397678®
1-800-NEWPORT

Newport Electronics, Inc.
2229 South Yale Street • Santa Ana, CA • 92704 • U.S.A.
TEL: (714) 540-4914 • FAX: (203) 968-7311
Toll Free: 1-800-639-7678 • www.newportUS.com • e-mail: info@newportUS.com
ISO 9001 Certified

Newport Technologies, Inc.
976 Bergar • Laval (Quebec) • H7L 5A1 • Canada
TEL: (514) 335-3183 • FAX: (514) 856-6886
Toll Free: 1-800-639-7678 • www.newport.ca • e-mail: info@newport.ca

Newport Electronics, Ltd.
One Omega Drive • River Bend Technology Centre
Northbank, Irlam • Manchester M44 5BD • United Kingdom
Tel: +44 161 777 6611 • FAX: +44 161 777 6622
Toll Free: 0800 488 488 • www.newportuk.co.uk • e-mail: sales@newportuk.co.uk

Newport Electronics B.V. - Benelux
TEL: +31 20 3472121 • FAX: +31 20 6434643
Toll Free: 0800 0993344 • www.newport.nl • e-mail: info@newport.nl

Newport Electronics spol s.r.o.
Frystatska 184, 733 01 Karviná • Czech Republic
TEL: +420 59 6311899 • FAX: +420 59 6311114
Toll Free: 0800-1-66342 • www.newport.cz • e-mail: info@newport.cz

Newport Electronics GmbH
Daimlerstrasse 26 • D-75392 Deckenpfronn • Germany
TEL: 49 7056 9398-0 • FAX: 49 7056 9398-29
Toll Free: 0800 / 6397678 • www.newport.de • e-mail: sales@newport.de

Newport Electronique S.A.R.L. - France
TEL: +33 1 61 37 29 00 • FAX: +33 1 30 57 54 27
Toll Free: 0800 466 342 • www.newport.fr • e-mail: sales@newport.fr

Mexico and Latin America
FAX: 001 (203) 359-7807
TEL En Español: 001 (203) 359-7803

NEWPORTnetSM On-Line Service www.newportUS.com	Internet e-mail info@newportUS.com
---	--

 **NEWPORT** Electronics, Inc.

10288ML-02 N